

Gala Shade Pro™

Congratulations on purchasing your new **Gala Shade™**. Your **Gala Shade™** will give you years of service and enjoyment if you follow these instructions carefully and take **care** of your **Gala Shade™** correctly. Please read the instructions before attempting to erect your **Gala Shade™** and save them for future reference.

We highly recommend that your **Gala Shade™** be insured against theft, adverse weather conditions and accidental Damage through incorrect assembly, improper storage and adverse weather conditions are not covered under the manufacturers guarantee.

Check the contents of the boxes in advance of using your **Gala Shade™** for the first time. We would recommend that you check that you have all the components at least 14 days prior to first using the product. Ensure that you are familiar with the erecting of the **Gala Shade™** and that all parts are accounted for. You should familiarise yourself with the structure including any restrictions it may have for your particular use. A **Gala Shade™** is a transportable structure, which under most circumstances will provide shelter against the elements. There are however extremes of weather for which allowance should be made.

Position:
Sheltered:
Weather:
Fair/Moderate

Gala Shade™ is not guaranteed waterproof. We do however endeavour to make them as weatherproof as possible. Where necessary/possible we have welded the seams but on some seams this is not feasible. It is therefore possible that a small amount of leakage may occur in heavy rain. Treating all sewn seams with a seam sealant, which is available from Gala Tent or your local dealer, can prevent this

Find a level piece of ground on which to erect your **Gala Shade™**. Ensure that you have enough help to lift the **Gala Shade™** without straining yourself or the frame.

Recommend required persons to erect the structure for guidance and safety.

3.0m x 3.0m = 2 persons
3.0m x 4.5m = 2 persons
3.0m x 6.0m = 3/4 persons

1. Take out the framework from the carry bag
2. Stand upright then using the required persons necessary pull out from all corners till 80% erect
3. Lay the roof cover over the frame
4. Now fully open the scissor action framework and fit the canopy cover in place over the corners
5. Extent the legs to the required height.

*IT IS IMPORTANT THAT YOU TAKE CARE IN WINDY WEATHER CONDITIONS. IT MAY BE NECESSARY TO TIE DOWN YOUR **GALA SHADE™** AT ANY STAGE DURING THE ASSEMBLY. WE DONOT RECOMMEND YOU LEAVE YOUR GALA SHADE ERECTED OVER NIGHT. AS THESE STRUCTURES CAN BE EASLIY TAKEN DOWN IN A FEW MINUTES WE RECOMMEND YOU STORE IN A COLL DRY PLACE THEN USE AGAIN THE FOLOWWING DAY.*

FIRE PRECAUTIONS - REMEMBER, YOUR GALA SHADE™ CAN BURN. FOLLOW THESE COMMON SENSE RULES

- When erecting, ensure there is a minimum distance of 6 metres between tents
- Do not place cooking, heating or lighting appliances near the sides or the roof of the **Gala Shade™**
- Always observe safety instructions for all appliances
- Keep exits clear and unobstructed
- Reverse the assembly instructions.

*TAKE GREAT **CARE** IN WINDY CONDITIONS AND ENSURE THAT YOU HAVE ENOUGH HELP TO PREVENT STRAIN ON THE FRAME. DRY ALL PARTS AT THE EARLIEST OPPORTUNITY. DO NOT STORE AWAY WET. YOUR **GALA SHADE™** IS NOT COVERED UNDER WARRANTY IF DAMAGE OCCURS DUE TO INCORRECT ERECTION, DISMANTLING, PACKING OR STORAGE*

Should you damage or lose any parts of your **Gala Tent™**, spares are available from **Gala Tent Ltd** direct.

IMPORTANT: Please note that storm, adverse weather and accident damage and damage through incorrect dismantle, erection, packing and storage is not covered by the warranty.



Manufactured By Gala Tent™

www.GalaTent.com

Unit 1 Park Springs, Springvale Road, Grimethorpe, Barnsley South Yorkshire S72 7BQ

Tel: + 44 (0) 870 4994 256 Fax: + 44 (0) 0870 499 2447